

<b><u>S.NO</u></b>	<b><u>SS ADAPTOR</u></b>
A1	1" X 1.1/4 " SS ADAPTOR (SINGLE HOOK)
A2	1" SS ADAPTOR
A3	1" SS ADAPTOR BOTTOM
A4	1" SS ADAPTOR (SINGLE HOOK)
A5	1.1/2" SS ADAPTOR
A6	1.1/2" SS ADAPTOR BOTTOM
A7	1.1/2" SS ADAPTOR BOTTOM (SINGLE HOOK)
A8	1.1/2 X 1.1/4" SS ADAPTOR
A9	1.1/2 X 1.1/4" SS ADAPTOR BOTTOM
A10	1.1/2 X 1.1/4" SS ADAPTOR BOTTOM (SINGLE HOOK)
A11	1.1/4 " SS ADAPTOR
A12	1.1/4 " SS ADAPTOR (H) (DOUBLE HOOK)
A13	1.1/4 " SS ADAPTOR (H) (SINGLE HOOK)
A14	1.1/4 " SS ADAPTOR (LONG)
A15	1.1/4 " SS ADAPTOR (SINGLE HOOK)
A16	1.1/4" SS ADAPTOR BOTTOM (L) (DOUBLE HOOK)
A17	1.1/4" SS ADAPTOR BOTTOM
A18	1.1/4" SS ADAPTOR BOTTOM (SINGLE HOOK)
A19	1.1/4 X 1" SS ADAPTOR
A20	1.1/4 X 1" SS ADAPTOR (SINGLE HOOK)
A21	1.1/4 X 1" SS ADAPTOR BOTTOM
A22	1.1/4 X 1" SS ADAPTOR BOTTOM (SINGLE HOOK)
A23	1.1/4 X 1.1/2"SS ADAPTOR BOTTOM (SINGLE HOOK)
A24	2" SS ADAPTOR
A25	2" SS ADAPTOR (DOUBLE HOOK )
A26	2" SS ADAPTOR BOTTOM
A27	2" SS ADAPTOR BOTTOM (SINGLE HOOK)
A28	2" SS ADAPTOR BOTTOM (DOUBLE HOOK)
A29	2.1/2" SS ADAPTOR
A30	2.1/2" SS ADAPTOR (DOUBLE HOOK)
A31	2.1/2" SS ADAPTOR BOTTOM
A32	2.1/2" SS ADAPTOR BOTTOM (DOUBLE HOOK)
A33	3" SS ADAPTOR BOTTOM

<u>S.NO</u>	<u>CI ADAPTOR</u>
A34	1" CI ADAPTOR
A35	1.1/2 X 1.1/4" CI ADAPTOR
A36	1.1/2" CI ADAPTOR
A37	1.1/2" CI ADAPTOR TOP
A38	1.1/2" CI ADAPTOR BOTTOM
A39	1.1/2 X 2" CI ADAPTOR
A40	1.1/2 X 2" CI ADAPTOR BOTTOM
A41	1.1/4" CI ADAPTOR
A42	1.1/4" CI ADAPTOR BOTTOM
A43	1.1/4" CI ADAPTOR TOP
A44	1.1/4 X 1" CI ADAPTOR
A45	1.1/4 X 1" CI ADAPTOR BOTTOM
A46	1.1/4 X 1.1/2" CI ADAPTOR
A47	1.1/4 X 1.1/2" CI ADAPTOR BOTTOM
A48	2" CI ADAPTOR (H)
A49	2" CI ADAPTOR TOP
A50	2" CI ADAPTOR BOTTOM
A51	2" X 1.1/2" CI ADAPTOR BOTTOM
A52	2" X 2.1/2" CI ADAPTOR
A53	2.1/2" CI ADAPTOR
A54	2.1/2" CI ADAPTOR BOTTOM
A55	2.1/2 X 2" CI ADAPTOR
A56	3" CI ADAPTOR