

MINIMEX
HAND GRINDER


คู่มือการใช้งาน
เครื่องบดกาแฟมือ
Minimex
รุ่น MHG1/MHG2



Instruction Manual HAND FROTHER


Model : MHG
ไทย / English

คุณสมบัติเครื่องบดกาแฟมือ



1. ขนาดกะทัดรัด, พกพาสะดวก
2. ประกอบด้วยตลับลูกปืนคู่ ช่วยให้การบดมีความสม่ำเสมอ
3. รูปทรงตัวเครื่อง ใช้งานได้เหมาะสมมือ
4. ปรับระดับการบดกาแฟได้ง่าย ด้วยการปรับภายนอก
5. แกนหมุนสเตนเลส สตีล แข็งแรง ทนทาน


ส่วนประกอบ




- ① ด้ามจับมือหมุน
- ② ฝาปิด
- ③ งานบดเมล็ดกาแฟ
- ④ โถใส่เมล็ดกาแฟบดแล้ว

- วัสดุตัวเครื่อง : อลูมิเนียม
- ปุ่มมือจับ : ไม้
- วัสดุโถใส่กาแฟบดแล้ว : อลูมิเนียม
- ปรับระดับการบด : 11 ระดับ (MHG1)
20 ระดับ (MHG2)
- ด้ามจับ : สเตนเลส สตีล 304


วิธีการใช้งาน



หมุนด้านนอกตัวเครื่องเพื่อปรับระดับการบิด






ประกอบโถล่างเข้ากับตัวเครื่อง และใส่เมล็ดกาแฟที่ด้านบน



ปิดฝาปิด (ด้ามจับ) จับเครื่องด้วยมือ(ข้างที่ถนัด) ใช้มืออีกข้างหมุนด้ามจับมือหมุนเพื่อเริ่มการบิด เมื่อบิดเสร็จแล้ว ถอดโถล่าง กาแฟสดพร้อมใช้งาน

ข้อแนะนำ



- การตั้งค่าเบอร์บิด
 - เบอร์บิดกาแฟมาก = บดหยาบ
จากตัวเครื่องให้หมุนตามเข็มนาฬิกา
 - เบอร์บิดกาแฟน้อย = บดละเอียด
จากตัวเครื่องให้หมุนทวนเข็มนาฬิกา
- การบิดกาแฟควรบิดเมื่อจะใช้งานเท่านั้น ไม่ควรค้างเมล็ดกาแฟไว้ในเครื่องเพราะน้ำมันในเมล็ดกาแฟอาจทำให้เพื่องบดติดขัดได้

- เครื่องบดนี้บดได้ปริมาณกาแฟต่อ 1-2 ซ็อตเท่านั้น
- การบิดกาแฟละเอียดจะใช้เวลานานกว่าระดับการบิดหยาบ
- หากการปรับระดับเบอร์บิดติดขัด ห้ามหมุนเครื่องแรงเพราะอาจทำให้เพื่องบดเสียหายได้ ให้หมุนคลายและค่อยปรับระดับใหม่

ข้อควรระวัง

- เครื่องบดกาแฟมือถือ ถูกออกแบบมาเพื่อการบิดกาแฟเท่านั้น
- หลังใช้งาน ใช้แปรงฟัดทำความสะอาดทุกครั้ง
- ห้ามให้เด็กอายุต่ำกว่า 8 ขวบใช้งาน หากเด็กใช้งาน ผู้พิการ หรือผู้ทุพพลภาพ ควรมีผู้ใหญ่ควบคุมดูแลอย่างใกล้ชิด
- ควรเก็บที่บิดกาแฟไว้ในที่แห้ง ไม่เปียกชื้น
- แนะนำระดับการบิดกาแฟที่ระดับ MHG1 : 3-11 (+0~3) / MHG2 : 15-20 (+0~15)
- การใช้เบอร์บิด 0-2 (MHG1) / 0-5 (MHG1) อาจทำให้เพื่องบดอยู่ในระยะขีด อาจบิดไม่ได้
- การซ่อมแซม ควรติดต่อศูนย์บริการ Minimax เบอร์ 02-493-6565 ไม่แนะนำให้ซ่อมแซมเอง หรือใช้ช่างอื่นในการซ่อมแซมเครื่อง

WARRANTY

เครื่องบดกาแฟมือรุ่น MHG1 และ MHG2 ระยะเวลาประกัน 1 ปี

เงื่อนไขการรับประกัน

การรับประกันครอบคลุมถึงคุณภาพของสินค้าและฝีมือการประกอบ ผู้ใช้ต้องใช้งานและบำรุงรักษาอย่างถูกต้องตามคำแนะนำในหนังสือคู่มือ

ข้อยกเว้นการรับประกัน

บริษัทฯ ขอสงวนสิทธิ์ในความรับผิดชอบต่อความเสียหายใดๆ ที่เป็นผลสืบเนื่องจากการใช้สินค้า และสงวนสิทธิ์การรับประกันหากลูกค้า :

- นำสินค้าไปใช้ผิดจากวัตถุประสงค์ของการออกแบบ
- ใช้งานผิดวิธีหรือไม่ได้ใช้งานตามวิธีที่อธิบายในหนังสือคู่มือ
- ไม่ได้บำรุงรักษาตามคำแนะนำในหนังสือคู่มือ

การใช้สิทธิ์การรับประกันสินค้า

การรับประกันสินค้ามีผลตามวันที่ที่ระบุในใบรับประกันสินค้า กรุณาแสดงใบรับประกันสินค้าหรือใบกำกับภาษี ใบเสร็จรับเงิน เพื่อเป็นหลักฐานในการขอต่อเจ้าหน้าที่ศูนย์บริการฯ ในการใช้สิทธิ์การรับประกันสินค้า การพิจารณาความบกพร่องของสินค้าเพื่อการรับประกัน บริษัทฯ จะทำการตรวจสอบสินค้าอย่างละเอียด และตัดสินใจว่า ความบกพร่องของสินค้านั้นอยู่ในเงื่อนไข การรับประกันหรือไม่ ซึ่งเป็นสิทธิ์ของบริษัทฯ เท่านั้น ในกรณีที่อยู่ในเงื่อนไขการรับประกัน บริษัทฯ จะเป็นผู้รับผิดชอบค่าแรงในการซ่อม ค่าอะไหล่และค่าจัดส่งสินค้าถึงบ้านลูกค้า โดยลูกค้าไม่ต้องชำระค่าบริการใดๆ ทั้งสิ้น

การพิจารณาความบกพร่องของสินค้าเพื่อการรับประกัน

บริษัทฯ จะทำการตรวจสอบสินค้าอย่างละเอียด และตัดสินใจว่า ความบกพร่องของสินค้านั้นอยู่ในเงื่อนไขการรับประกันหรือไม่ ซึ่งเป็นสิทธิ์ของบริษัทฯ เท่านั้น ในกรณีที่อยู่ในเงื่อนไขการรับประกัน บริษัทฯ จะเป็นผู้รับผิดชอบค่าแรงในการซ่อม ค่าอะไหล่ และค่าจัดส่งสินค้าถึงบ้านลูกค้า โดยลูกค้าไม่ต้องชำระค่าบริการใดๆ ทั้งสิ้น หากบริษัทฯ พิจารณาเห็นว่า ต้องเปลี่ยนสินค้าใหม่ให้แก่ลูกค้าแต่สินค้ารุ่นเดียวกันไม่มีจำหน่ายแล้ว บริษัทฯ จะเป็นผู้ตัดสินใจว่า สินค้ารุ่นใดเหมาะสมที่จะเปลี่ยนแทน

การคืนสินค้า


ในกรณีที่ลูกค้าซื้อสินค้าไปแล้วแต่ไม่ถูกใจ บริษัทฯ ยินดีรับคืนสินค้าภายใน 15 วัน โดยมีเงื่อนไขว่า สินค้าต้องมีบรรจุภัณฑ์อย่างสมบูรณ์และสินค้าไม่ได้ถูกใช้งานมาก่อน โดยลูกค้าต้องนำหลักฐานการซื้อเพื่อคืนสินค้า ณ ร้านค้าที่ซื้อเท่านั้น

ศูนย์บริการ

หากท่านต้องการบริการรายละเอียดเพิ่มเติมหรือสั่งซื้ออุปกรณ์พิเศษท่านสามารถติดต่อศูนย์บริการฯ ได้
Service Center : Tel. 02-493-6565, LineOA : @minimax_service
E-mail : SERVICE_minimax@penk.co.th




HAND GRINDER FEATURES



1. Compact design, easy to carry.
2. Double bearing positioning movement grinding more uniform.
3. Easy to hold surface touch design variety.
4. External fine grinding adjustment design.
5. High hardness stainless steel core.


KNOW YOUR HAND GRINDER




- ① Hand controller
- ② Handle cover
- ③ Regulating disc
- ④ Powder bin

- Body : Aluminum alloy
- Handle bead : Solid wood
- Powder bin : Aluminum alloy
- Effective use scale :
MHG1 : 14 knots
MHG2 : 20 knots
- Handle rocker : 304 stainless steel


METHOD OF APPLICATION



Rotate around the outside of the main body to adjust the desired grinding thickness.




Tighten the powder bin, open the top handle cover, and pour the beans from the top.




Close the lid of the handle, hold the adjusting piece between the powder bin with one hand, and grind with the handle with the other hand. After grinding, spin out the powder bin and pour out the coffee powder.

DETAILED GRINDING SCALE




Espresso, Moka pot

Siphon, Pour over, Aero Press,
French Press



Espresso, Moka pot

Siphon, Pour over, Aero Press,
French Press



- Turn counterclockwise to adjust fine grinding, turn clockwise to adjust coarse grinding
- The product shipping scale has been calibrated and rotated counterclockwise to the thinnest limit hand
- The handle cannot be turned (11- 0 knots), which is the origin. Grinding degree table is only our experience estimate, for reference only, daily use
- Use can be slightly adjusted to personal preference.

- The finer the grinding, the longer it takes, and the coarser the shorter the vice versa.
- When the machine is adjusted to the tightest, do not rotate hard to avoid damaging the grinding core.

MATTERS NEED ATTENTION

- This equipment is only designed for ground and roasted coffee beans, please do not Grind other products.
- It is recommended to use a brush device for cleaning, do not wash.
- Core edge is sharp, please be careful to avoid scratches.
- Do not allow children to handle this product.
- Store this product in a dark and dry environment.
- When grinding beans with FXMINI, it is recommended to work in sections
MHG1 : 3-11 (+0~3) / MHG2 : 15-20 (+0~15), 0-2 section for core protection, can not be grinding
- It is not recommended to disassemble the core and other internal components by yourself. If you have special needs, please carry out under the guidance of relevant technical personnel.

WARRANTY

We hereby warranty our Minimex Hand Grinder MHG1 and MHG2 in a period of 1 (one) year.

Warranty Conditions

The warranty cover product defective and workmanship . Users must properly use and maintain following the instructions manual.

Warranty exceptions

We disclaims all responsibility for incidental or consequential damage caused by use of this appliance This warranty will be void if customers.

- lead to a misunderstanding of the purpose of the design, such as using product in a commercial use.
- Use the wrong way or not used as described in the instruction manual.
- no maintenance as recommended in the instruction manual.

Customer right for product warranty

The warranty is effective on the date specified in the warranty card , invoice or receipt as proof of purchase.

Determination of defective product

The company will inspect the false or defective of the product and decide that the defective of the product is in warranty or not. The decision is solely the rights of the company. If the product proved to be defected and covered by warranty, company will be responsible for parts and labor to repair and deliver the product to customers' house. Customers do not have to pay any fee. If the company considers that it must change its products to customers, but the same model of product is not available, the company will determine an appropriate version of the product to be replaced.

Returns of Product

If customer purchases to be dissatisfy. Customer could return the product within 15 days after purchasing date only if the product is completely perfect packaging and has not been used before. Customers must present proof of purchase to return the product at the store of purchase only.

Service Center

If customer need service or information, customer can contact our Minimex Service Center
Service Center : Tel. 02-493-6565, LineOA : @minimex_service
E-mail : SERVICE_minimex@penk.co.th