


HÄFELE

คู่มือการใช้งาน
เครื่องฟอกอากาศ 25 ตร.ม.
495.38.950



โปรดอ่านคู่มืออย่างละเอียดก่อนใช้งาน
ถอดถุงพลาสติกใส่กรองด้านในเครื่องฟอกอากาศก่อนการใช้งานครั้งแรก

บริษัท เฮเฟล่ (ประเทศไทย) จำกัด
57 ซอยสุขุมวิท 64 ถนนสุขุมวิท แขวงพระโขนงใต้ เขตพระโขนง กรุงเทพฯ 10260
โทรศัพท์: +66 (0) 2768 7171

กรุณาอ่านและเก็บรักษาคู่มือนี้ไว้

คำเตือน หากไม่ปฏิบัติตามคำเตือนต่อไปนี้ อาจส่งผลให้เกิดไฟฟ้าช็อตหรือบาดเจ็บร้ายแรงได้




ผลิตภัณฑ์นี้ควรใช้งานตามข้อกำหนดที่ระบุไว้ในคู่มือฉบับนี้เท่านั้น

- กรุณาอ่านคู่มือผู้ใช้อย่างละเอียดก่อนใช้งาน และเก็บไว้สำหรับอ้างอิงในอนาคต
- เพื่อหลีกเลี่ยงไฟไหม้ ควรเก็บเครื่องฟอกอากาศไว้ในที่แห้งและเย็น ห่างจากแหล่งความร้อนและความชื้น ห้ามทิ้งไว้ในที่อุณหภูมิสูง เช่น ภายในรถที่จอดตากแดด
- ควรวางสายไฟให้พ้นจากบริเวณที่มีคนเดินผ่านไปมา เพื่อลดความเสี่ยงในการสะดุด
- ห้ามวางสายไฟใต้พรมหรือใกล้แหล่งความร้อน เช่น หม้อน้ำ เต้า หรือเครื่องทำความร้อน เนื่องจากอาจเกิดอันตรายจากไฟไหม้
- เพื่อความปลอดภัยทางไฟฟ้า ห้ามจุ่มผลิตภัณฑ์ลงในน้ำหรือของเหลวอื่นๆ และหลีกเลี่ยงการใช้งานใกล้แหล่งน้ำ
- เด็กอาจไม่รับรู้ถึงอันตรายที่อาจเกิดจากการใช้เครื่องใช้ไฟฟ้า ควรดูแลเด็กอย่างใกล้ชิดเมื่ออยู่ใกล้เครื่อง
- เด็กควรได้รับการควบคุมดูแล เพื่อให้แน่ใจว่าจะไม่เล่นเครื่องใช้ไฟฟ้า
- ควรถอดปลั๊กทุกครั้งก่อนเคลื่อนย้ายเครื่อง เปิดตะแกรง เปลี่ยนไส้กรอง ทำความสะอาด หรือเมื่อไม่ได้ใช้งาน
- ห้ามใช้งานเครื่องหากสายไฟหรือปลั๊กชำรุด พัดลมมอเตอร์ไม่หมุน หรือเครื่องได้รับความเสียหายไม่ว่าด้วยสาเหตุใด ให้ติดต่อฝ่ายบริการลูกค้า
- ใช้เครื่องนี้สำหรับการใช้งานภายในบ้านตามที่ระบุไว้ในคู่มือเท่านั้น การใช้งานอื่นที่ไม่ได้รับคำแนะนำจากผู้ผลิต อาจทำให้เกิดไฟไหม้ ไฟฟ้าช็อต หรือเป็นอันตรายต่อร่างกาย
- ห้ามใช้เครื่องภายนอกอาคาร
- ห้ามวางสิ่งของใดๆ บนตัวเครื่อง
- ห้ามซ่อมหรือปรับแต่งส่วนใดๆ ของเครื่องด้วยตนเอง เพราะจะทำให้การรับประกันสิ้นสุดลง การซ่อมแซมทั้งหมดควรกระทำโดยช่างผู้เชี่ยวชาญเท่านั้น
- อย่าให้เครื่องใช้ไฟฟ้าทำงาน ถ้าเครื่องใช้ไฟฟ้าเสียหายอย่างเห็นได้ชัด

- ถ้าสายอ่อนจ่ายกำลังไฟชำรุด ต้องให้ผู้ทำหรือตัวแทนฝ่ายบริการหรือผู้ที่มีคุณสมบัติคล้ายกัน เป็นผู้เปลี่ยน เพื่อหลีกเลี่ยงอันตราย
- ห้ามปิดกั้นช่องลมเข้า-ออกหรือช่องตะแกรง และห้ามวางเครื่องบนพื้นผิวที่อ่อนนุ่ม เช่น เบาะหรือโซฟา เพราะอาจทำให้เครื่องล้นและขัดขวางการไหลเวียนของอากาศได้

ข้อมูลทางเทคนิค

- 220-240 โวลต์, 50/60 เฮิร์ตซ์, 25 วัตต์
- ขนาด: 215 x 215 x 355 มม.
- ระดับเสียง: 26-50 เดซิเบล
- พื้นที่ใช้งานที่เหมาะสม: มากกว่า 25 ตารางเมตร



ระบบทำความสะอาดอากาศ

ปรับปรุงคุณภาพอากาศภายในบ้านของคุณด้วยระบบทำความสะอาดอากาศแบบหลายขั้นตอน

1. ไส้กรอง Pre-Filter: กรองฝุ่นและอนุภาคขนาดใหญ่
2. ไส้กรอง H13 HEPA: กรองฝุ่น คิวบิน เกสรดอกไม้ และสารก่อภูมิแพ้
3. ไส้กรอง Carbon: ขจัดกลิ่นไม่พึงประสงค์

คำแนะนำการใช้งาน

ก่อนเริ่มใช้งานเครื่องฟอกอากาศ:


1. การเตรียมตัว: เมื่อใช้งานเครื่องฟอกอากาศเป็นครั้งแรก ให้นำเครื่องออกจากกล่องและเอาถุงพลาสติกสองถุงออกจากตัวเครื่องและไส้กรอง
2. ข้อกำหนดพื้นผิว: วางเครื่องฟอกอากาศบนพื้นผิวที่มั่นคงและราบเรียบ



หมายเหตุ:

1. ควรเว้นระยะห่างอย่างน้อย 15 นิ้ว / 38 ซม. จากทุกด้านของเครื่อง เพื่อให้การไหลเวียนอากาศดี
2. หลีกเลี่ยงการวางเครื่องใกล้สิ่งนี้อาจขัดขวางการไหลเวียนของอากาศ

การใช้งานเครื่องฟอกอากาศ



สัญลักษณ์	คำอธิบาย
	เปิด/ปิดเครื่อง
	กดปุ่มนี้สั้นๆ เพื่อเปิด/ปิดเครื่อง
	โหมดการนอนหลับ
	- กดปุ่มนี้เพื่อเข้าสู่โหมดการนอนหลับ (ไอคอนจะกระพริบ 5 วินาที) - ในโหมดการนอนหลับ ไฟทั้งหมด (ยกเว้นปุ่มโหมดการนอนหลับ) จะปิด และเครื่องจะทำงานที่ความเร็วการนอนหลับโดยอัตโนมัติ กดปุ่มใดๆ เพื่อออกจากโหมดนี้

สัญลักษณ์	คำอธิบาย		
	ความเร็วพัดลม & การเปลี่ยนไส้กรอง		
	- ความเร็วพัดลม: กดปุ่มนี้สั้น ๆ เพื่อสลับการตั้งค่าความเร็วระหว่าง ความเร็วต่ำ (I), ความเร็วกลาง (II) และความเร็วสูง (III) - การรีเซ็ตไส้กรอง: กดปุ่มนี้ค้างไว้ 3-5 วินาที เพื่อรีเซ็ตไส้กรอง		
	สัญญาณไฟแสดงสถานะ		
		ไฟจะสว่างเป็นสีขาวเมื่ออยู่ในโหมดความเร็วต่ำ	
		ไฟจะสว่างเป็นสีขาวเมื่ออยู่ในโหมดความเร็วปานกลาง	
		ไฟจะสว่างเป็นสีขาวเมื่ออยู่ในโหมดความเร็วสูง	
		เมื่อไฟแสดงสถานะเปลี่ยนเป็นสีแดง แสดงว่าควรเปลี่ยนไส้กรอง และไฟสีแดงจะดับลงเมื่อทำการรีเซ็ตไส้กรองเรียบร้อยแล้ว	
	โหมดอัตโนมัติ		
	- กดปุ่มนี้เพื่อเปิดหรือปิดโหมดอัตโนมัติ - เมื่ออยู่ในโหมดอัตโนมัติ เครื่องจะปรับความเร็วพัดลมโดยอัตโนมัติตามคุณภาพอากาศที่ตรวจจับได้จากเซ็นเซอร์		
	คุณภาพอากาศ	สีของวงแหวนไฟ LED	ความเร็วพัดลม (ในโหมดอัตโนมัติ)
	ดี	น้ำเงิน	ความเร็วต่ำ
	ปานกลาง	เหลือง	ความเร็วกลาง
	มีมลพิษเล็กน้อย	ส้ม	ความเร็วสูง
	มลพิษมาก	แดง	ความเร็วสูง

สัญลักษณ์	คำอธิบาย
	ระบบล็อกปุ่มเพื่อป้องกันเด็ก
	- กดปุ่มนี้ค้างไว้เพื่อเปิดหรือปิดฟังก์ชันป้องกันเด็ก - เมื่อเปิดใช้งาน ไฟแสดงสถานะจะสว่างเป็นสีขาว
	ตั้งเวลา
	กดปุ่มนี้สั้นๆ เพื่อเลือกเวลาปิดเครื่องอัตโนมัติ: 2 ชั่วโมง, 4 ชั่วโมง, 8 ชั่วโมง หรือปิดการตั้งเวลา
	สัญญาณไฟแสดงสถานะ
	2h ไฟจะสว่างเป็นสีขาวเมื่อเลือกตั้งเวลา 2 ชั่วโมง
	4h ไฟจะสว่างเป็นสีขาวเมื่อเลือกตั้งเวลา 4 ชั่วโมง
	8h ไฟจะสว่างเป็นสีขาวเมื่อเลือกตั้งเวลา 8 ชั่วโมง

การทำความสะอาดและการดูแลรักษา

การทำความสะอาดเครื่องฟอกอากาศอย่างเหมาะสมจะช่วยให้เครื่องทำงานได้อย่างมีประสิทธิภาพ

• การทำความสะอาดทั่วไป

1. ปิดเครื่องและถอดปลั๊กก่อนทำความสะอาด
2. ใช้ผ้านุ่มสะอาดและแห้งเช็ดบริเวณด้านนอกของเครื่อง
3. ใช้ผ้าแห้งหรือแปรงนุ่มทำความสะอาดช่องลมเข้าและช่องลมออก



หมายเหตุในการทำความสะอาด

1. ห้ามใช้สารเคมีรุนแรงหรือสารทำความสะอาดที่ติดไฟได้
2. แนะนำให้ทำความสะอาดเครื่องอย่างน้อยเดือนละ 1 ครั้ง
3. ห้ามนำเครื่องฟอกอากาศไปแช่น้ำหรือจมน้ำโดยตรง
4. ห้ามสอดนิ้วมือหรือสิ่งแปลกปลอมเข้าไปในตัวเครื่อง
5. ห้ามใช้เบนซิน ทินเนอร์ น้ำยาทำความสะอาดที่มีฤทธิ์กัดกร่อน หรือแอลกอฮอล์ในการทำความสะอาด เพราะอาจทำให้เครื่องเสียหาย

• การตรวจสอบไฟแสดงสถานะไส้กรอง

อายุการใช้งานไส้กรองและไฟแสดงสถานะ

ไส้กรองมีอายุการใช้งานประมาณ 6 เดือน ทั้งนี้ขึ้นอยู่กับการใช้งานและคุณภาพอากาศในแต่ละพื้นที่ เมื่อถึงเวลาที่ต้องเปลี่ยนไส้กรอง ไฟแสดงสถานะ  จะเปลี่ยนเป็นสีแดง


• การเปลี่ยนไส้กรอง

ควรเปลี่ยนไส้กรองทุก ๆ 6 เดือน อย่างไรก็ตาม ระยะเวลาในการเปลี่ยนไส้กรองอาจเร็วหรือช้ากว่านี้ ขึ้นอยู่กับความถี่ในการใช้งานเครื่องฟอกอากาศของคุณ กรุณาทำตามขั้นตอนด้านล่างเพื่อเปลี่ยนไส้กรองอย่างถูกวิธี



หมายเหตุ: โปรดฉีกถุงพลาสติกของไส้กรองใหม่ออกก่อนใส่เข้าตัวเครื่อง

1. ปิดเครื่องและถอดปลั๊กออกจากแหล่งจ่ายไฟ
2. หมุนและยกฝาครอบฐานออก
3. นำไส้กรองเก่าออก และใส่ไส้กรองใหม่เข้าไปให้แน่นสนิท จากนั้นปิดฝาครอบฐานกลับเข้าที่ให้เรียบร้อย



• การรีเซ็ตไฟแสดงสถานะไส้กรอง

1. หลังจากเปลี่ยนไส้กรองใหม่แล้ว ให้เปิดเครื่องฟอกอากาศ
2. กดปุ่ม  บนแผงควบคุมค้างไว้ 3-5 วินาทีเพื่อรีเซ็ต
3. ไฟแสดงสถานะการเปลี่ยนไส้กรอง  จะดับลง เมื่อรีเซ็ตสำเร็จ

• การเก็บรักษา

เมื่อเตรียมเก็บเครื่องฟอกอากาศหลังจากไม่ได้ใช้งานเป็นระยะเวลานาน ให้ทำตามคำแนะนำเหล่านี้เพื่อยืดอายุการใช้งานของเครื่อง:

1. แนะนำให้ทำความสะอาดเครื่องก่อนเก็บ
2. บรรจุเครื่องฟอกอากาศและไส้กรองในบรรจุภัณฑ์พลาสติกและเก็บในที่เย็นและแห้ง หลีกเลี่ยงการเก็บในที่ที่มีแสงแดดตรงหรืออุณหภูมิที่สูงเกินไป

การหาสาเหตุและแก้ไขปัญหา

ปัญหา	สาเหตุที่เป็นไปได้	วิธีการแก้ไข
ไม่สามารถเปิดเครื่องได้	การเชื่อมต่อไฟฟ้า	ตรวจสอบให้แน่ใจว่าปลั๊กไฟเชื่อมต่ออย่างแน่นหนา หากไม่แน่นให้ถอดปลั๊กแล้วเสียบใหม่
	สภาพของเต้ารับ	ตรวจสอบว่าเต้ารับทำงานได้หรือไม่
การไหลเวียนอากาศลดลง	ระยะห่างหรือช่องว่างไม่เพียงพอ	ควรเว้นระยะห่างอย่างน้อย 15 นิ้ว / 38 ซม. จากทุกด้านของเครื่องฟอกอากาศ

ปัญหา	สาเหตุที่เป็นไปได้	วิธีการแก้ไข
การไหลเวียนอากาศลดลง	ไส้กรองสกปรก	ไส้กรองไม่สะอาด ทำความสะอาดหรือเปลี่ยนไส้กรองใหม่หากจำเป็น
เสียงดัง	เครื่องวางไม่ตรง	ตรวจสอบให้แน่ใจว่าเครื่องวางอยู่บนพื้นผิวที่เรียบและมั่นคง
	ตำแหน่งไส้กรองไม่ถูกต้อง	ตรวจสอบให้แน่ใจว่าไส้กรองถูกนำออกจากบรรจุภัณฑ์และติดตั้งอย่างถูกต้อง
	ไส้กรองสกปรก	ไส้กรองไม่สะอาด เปลี่ยนไส้กรองใหม่หากจำเป็น
	ไส้กรองเสียหาย	ตรวจสอบไส้กรองว่ามีความเสียหายหรือไม่ หากเสียหายให้เปลี่ยนใหม่
	ไส้กรองสกปรก	ทำความสะอาดไส้กรองหรือเปลี่ยนใหม่หากจำเป็น
กลิ่นไม่พึงประสงค์	ต้องเปลี่ยนไส้กรอง	เปลี่ยนไส้กรองอากาศแล้วกดปุ่มรีเซ็ตค้างเพื่อรีเซ็ตสถานะ
ไฟแสดงสถานะไส้กรองเป็นสีแดง	ต้องเปลี่ยนไส้กรอง	เปลี่ยนไส้กรองอากาศแล้วกดปุ่มรีเซ็ตค้างเพื่อรีเซ็ตสถานะ

คำแนะนำและข้อมูลเกี่ยวกับการทิ้งวัสดุบรรจุภัณฑ์ที่ใช่แล้ว

ทิ้งวัสดุบรรจุภัณฑ์หรือกล่องกระดาษในสถานที่กำจัดขยะสาธารณะ

การกำจัดเครื่องใช้ไฟฟ้าและอุปกรณ์อิเล็กทรอนิกส์ที่ใช่แล้ว



ความหมายของสัญลักษณ์บนผลิตภัณฑ์ อุปกรณ์เสริม หรือบรรจุภัณฑ์ เป็นการระบุว่าผลิตภัณฑ์นั้นไม่ควรได้รับการกำจัดเหมือนเป็นขยะทั่วไปในครัวเรือน กรุณากำจัดผลิตภัณฑ์นี้ ณ จุดรวบรวมสำหรับการรีไซเคิลขยะประเภทอุปกรณ์ไฟฟ้าและอิเล็กทรอนิกส์

สำหรับอีกทางเลือกหนึ่งในบางรัฐของสหภาพยุโรปหรือรัฐอื่นๆ ในยุโรป อาจส่งคืนผลิตภัณฑ์เก่าของคุณไปยังผู้ค้าปลีกในพื้นที่ของคุณเมื่อซื้อผลิตภัณฑ์ใหม่ที่เทียบเท่าการกำจัดที่ถูกต้องนี้จะช่วยประหยัดทรัพยากรธรรมชาติที่มีค่า และช่วยในการป้องกันผลกระทบเชิงลบที่อาจเกิดขึ้นต่อสิ่งแวดล้อมและสุขภาพของมนุษย์ซึ่งอาจเกิดจากการกำจัดของเสียที่ไม่เหมาะสม โปรดสอบถามหน่วยงานในพื้นที่ของคุณหรือศูนย์รวบรวมขยะที่ใกล้ที่สุดสำหรับรายละเอียดเพิ่มเติม การกำจัดของเสียประเภทนี้อย่างไม่เหมาะสมอาจก่อให้เกิดค่าปรับได้สำหรับในบางประเทศ

สำหรับหน่วยงานในสหภาพยุโรป

หากคุณต้องการทิ้งอุปกรณ์ไฟฟ้าหรืออิเล็กทรอนิกส์ โปรดขอข้อมูลที่จำเป็นจากผู้ขายหรือซัพพลายเออร์ของคุณ

การกำจัดในประเทศอื่นๆ นอกสหภาพยุโรป

หากคุณต้องการทิ้งผลิตภัณฑ์นี้ โปรดขอข้อมูลที่จำเป็นเกี่ยวกับวิธีการกำจัดที่ถูกต้องจากหน่วยงานรัฐบาลท้องถิ่นหรือจากผู้ขายของคุณ



ผลิตภัณฑ์นี้ เป็นไปตามข้อกำหนดพื้นฐานตามกฎหมายบังคับที่เกี่ยวข้องของสหภาพยุโรปการเปลี่ยนแปลงข้อความ การออกแบบ และข้อกำหนดทางเทคนิค อาจเกิดขึ้นได้โดยไม่ต้องแจ้งให้ทราบล่วงหน้าและเราขอสงวนสิทธิ์ในการเปลี่ยนแปลงเหล่านี้

การรับประกัน

คำจำกัดความการรับประกันสินค้า

1. วันที่ได้รับการประกันสินค้าคือวันที่ลูกค้าได้รับสินค้าที่ระบุตามใบเสร็จรับเงิน
2. ลูกค้าต้องทำการลงทะเบียนรับการประกันสินค้าผ่านทางออนไลน์บนหน้าเว็บไซต์ของบริษัทตามลิงค์นี้ <https://app.hafele.co.th/warranty#/> หรือ สแกนผ่าน QR code ด้านล่างนี้ทันทีหลังจากที่ได้รับสินค้านี้ หากไม่ทำการลงทะเบียนการรับประกันสินค้า จะไม่อยู่ในข่ายของการรับประกันของทางบริษัททุกกรณี
3. การรับประกันสินค้าตามเงื่อนไขของบริษัทนั้น จะไม่ครอบคลุมในเรื่องการใช้งานผิดวิธีและนอกเหนือจากคำแนะนำ หรือความผิดพลาดจากผู้ใช้งาน
4. สินค้าจะต้องอยู่ในกล่องบรรจุภัณฑ์พร้อมอุปกรณ์เสริมต่างๆ ต้องอยู่ครบถ้วน




ใบรับประกันสินค้า

1. สินค้าที่ต้องการบริการหลังการขาย จำเป็นต้องใช้เอกสารประกอบ ดังนี้
 - ใบส่งของหรือหมายเลขคำสั่งซื้อ
 - ใบกำกับภาษีหรือใบเสร็จรับเงิน (ถ้ามี)
 - ใบรับประกัน (บริษัทจะนับจากกรณีที่ลูกค้าลงทะเบียนรับประกันเท่านั้น)
 2. อุปกรณ์เสริมหรืออะไหล่ต่างๆ และบรรจุภัณฑ์ที่เกิดความเสียหายจากการขนส่ง ไม่อยู่ในเงื่อนไขของการรับประกัน
- โปรดลงทะเบียนผลิตรถยนต์ภายใน 14 วันหลังจากวันที่ซื้อ
 (ต้องแนบใบเสร็จรับเงินต้นฉบับหรือใบเสร็จรับเงินอิเล็กทรอนิกส์ของการซื้อหรือหมายเลขคำสั่งซื้อที่ทำการสั่งซื้อโดยตรงกับทางช่องทาง E-Commerce ของบริษัทฯ เท่านั้น)

HÄFELE

INSTRUCTION MANUAL AIR PURIFIER 25 SQ.M 495.38.950



**Please read the manual carefully before using the product.
Remove the plastic packaging from the filter before first use.**

Häfele (Thailand) Co., Ltd.
57 Soi Sukhumvit 64, Sukhumvit Road, Prakanong Tai, Phrakanong,
Bangkok 10260, Phone: +66 (0) 2768 7171

READ AND SAVE THESE INSTRUCTIONS

WARNINGS Failure to comply with the warnings listed below may result in electric shock or serious injury.


 This product should be used only following the specifications outlined in this manual.

- Please read the user manual thoroughly before using the product and keep it for future reference.
- To avoid fire, always keep the air purifier in a cool, dry place away from the heat sources and moisture. Do not leave the product in high-temperature environments, such as a car exposed to direct sunlight.
- Keep the power cord clear of high-traffic areas to prevent tripping hazards.
- To avoid fire hazards, never put the cord under rugs or place it near heat sources like radiators, stoves, or heaters.
- To ensure electrical safety, do not immerse the product in water or other liquids, and avoid using it near water sources.
- Children may not recognize the potential dangers of using electrical appliances. Always supervise children when they are near the unit.
- Children should be supervised to ensure they do not play with the appliance.
- Always unplug the unit before moving it, opening the grill, changing filters, cleaning, or when it is not in use.
- Do not operate the unit if the cord or plug is damaged, if the motor fan fails to rotate, or if it has been damaged in any manner. Contact customer service for assistance.

- Use the unit only for household purposes described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not place any objects on top of the unit.
- Do not attempt to repair or adjust any electrical or mechanical functions of the unit, as this will void your warranty. All servicing should be performed by qualified personnel only.
- Do not operate the appliance if it is visibly damaged.
- If the power supply cord is damaged, it must be replaced by the manufacturer, its service agent, or a similarly qualified person to avoid hazards.
- Do not block the air inlets, air outlets and grills, or place the unit on soft surface such as bed or sofa, as this could cause the unit to tip over and obstruct airflow.

TECHNICAL DATA

- 220-240V, 50/60Hz, 25W
- Dimensions: 215 x 215 x 355 mm
- Noise level: 26-50 dB
- Applicable area: 25m²+



AIR CLEANING SYSTEM

Improve your indoor air quality with multiple Air Cleaning System.

1. **Pre-Filter:** Captures initial large particles and dust.
2. **H13 HEPA Filter:** Captures dust, smoke, pollen, and other allergens.
3. **Carbon Filter:** Eliminates odors and bad smells.

OPERATING INSTRUCTIONS

BEFORE OPERATING THE AIR PURIFIER:


1. **Preparation:** When using your air purifier for the first time, lift your air purifier from the box and remove two pack plastic bags from unit and filter.
2. **Surface Requirements:** Always place the purifier on a firm, level and flat location for the air purifier.



Remarks

1. For proper air flow, allow at least 15 inches / 38 cm of clearance on all sides of the unit.
2. Keep away from anything that would block airflow.

OPERATING THE AIR PURIFIER



ICON	DESCRIPTIONS
	Power
	Power: Short press this button to turn on/off the unit.
	Sleep Mode
	- Press this button to enter (with icon flashing for 5 seconds) sleep mode. - Under sleep mode, all lights (except for sleep mode button) will turn off and the unit will be working by default sleep speed, press any button to exit sleep mode.

ICON	DESCRIPTIONS		
	Fan Speed & Filter Replacement		
	- Fan Speed: Short press this button to cycle through the speed settings between Low Speed (I), Medium Speed (II) and High Speed (III). - Filter Replacement: Long press this button for 3-5 seconds for filter reset.		
	Indicator		
		The indicator will illuminate white for Low Speed.	
		The indicator will illuminate white for Medium Speed.	
		The indicator will illuminate white for High Speed.	
		Replace the filter when this indicator turns red. And the red indicator will be off if your perform filter reset successfully.	
	AUTO Mode		
	- Press this button to enter or exit AUTO Mode. - Under auto mode, the unit will automatically change the fan speed according to the air quality detected by the air sensor.		
	Air Quality	LED Ring Color	Fan Speed under AUTO
	Good	Blue	Low speed
	Moderate	Yellow	Medium speed
	Lightly polluted	Orange	High speed
	Heavily polluted	Red	High speed

ICON	DESCRIPTIONS	
	Child Lock	
	- Child Lock: Long press this button to turn on or turn off Child Lock function. - The indicator will illuminate white if child lock function is enabled.	
	Timer	
	Timer: Short press this button to cycle through the timer settings between 2h,4h,8h and OFF.	
	Indicator	
	2h	The indicator will illuminate white to confirm your 2h timer selection.
	4h	The indicator will illuminate white to confirm your 4h timer selection.
	8h	The indicator will illuminate white to confirm your 8h timer selection.

CLEANING & MAINTAINING

Proper cleaning of your air purifier is essential to maintain optimal performance.

- **GENERAL CLEANING**

1. Turn off and unplug the unit before cleaning.
2. Wipe the outside of the air purifier with a clean, soft and dry cloth.
3. Clean the air inlet and air outlet with a soft dry cloth or brush.



Note:

1. Never clean with abrasive chemicals or flammable cleaning agents.
2. It is recommended to clean the unit at least once a month.
3. Do not put the air purifier in water or spray water directly on it.
4. Do not stick any foreign objects or your fingers inside the unit.
5. Do not use gasoline, benzene, thinner, harsh cleaners, etc. on and/or in the unit while cleaning as they will damage the products. Never use alcohol or other solvents.

- **FILTER INDICATOR CHECK**

Depending on usage and your air quality conditions, the filter will last approximately 6 months. The filter replacement indicator  will illuminate red when it is time to replace the filter.


• FILTER REPLACEMENT

The filter should be replaced every 6 months. You may need to replace your filter earlier or later depending on how often you use your air purifier. Follow the instructions below to change the filter.



Note: Remember to tear off the packing bag of the new filter before replacing it.

1. Turn off and unplug the air purifier.
2. Rotate and lift the base cover.
3. Remove the old filter and replace it with a new one. Ensure that it is securely fitted in place, then reattach the base cover.



• FILTER INDICATOR RESET

1. After replacing filter, turn on the air purifier.
2. Press and hold the button  on the control panel for 3-5 seconds to reset it.
3. The filter replacement indicator  will turn off when successfully reset.

• STORAGE

When preparing to store your air purifier after extended periods of non-use, follow these instructions to ensure the longevity of the unit:

1. Cleaning is recommended before storage.
2. Pack both the air purifier and the filter in plastic packing and store in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Unable to Power On	Power Connection	Ensure the power plug is securely connected. Unplug and then reconnect the unit.
	Outlet Condition	Check if the power outlet works.
Reduced Airflow	Insufficient Clearance	Maintain at least 15 inches or 38 cm of clearance on all sides of the air purifier.

PROBLEM	POSSIBLE CAUSE	SOLUTION
Reduced Airflow	Dirty Filter	Filter isn't clean. Clean or replace it with a new one if necessary.
Loud Noise	Level Placement	Ensure the unit is on a flat, stable surface.
	Improperly Positioned Filter	Make sure the filter is removed from its packaging and properly in place.
	Dirty Filter	Filter isn't clean. Replace with a new one if necessary.
	Damaged Filter	Check the filter for damage. If damaged, replace with a new one.
Unpleasant Odors	Dirty Filter	Clean the filter or replace it if necessary.
Filter Indicator Illuminated Red	Filter replacement needed	Replace the air filter, then press and hold the reset button to reset.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste.

Alternatively, in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection center for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



meets all the basic EU regulation requirements that relate to it.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.

WARRANTY

EFFECTIVE DEFINITION OF PRODUCT WARRANTY

1. The date the warranty will start from the date that specify on receipt or invoice.
2. Customers must register for product warranty online on the Company's website at this link <https://app.hafele.co.th/warranty#/> or scan via QR code below immediately after receiving this product. If not registered, the product will not be covered by the company's warranty in all cases.
3. If misuse and in addition to any advice or error from the users, the warranty will not cover all cases.
4. The product must be in the package with all accessories complete.



PRODUCT WARRANTY CERTIFICATE

1. Product after-sales service valid warranty certificate such as
 - Delivery noted or various order numbers of purchase.
 - Invoice or receipt (if any).
 - Warranty card (the company will count from the case that the customer registers the warranty only).
2. Accessories or spare parts and packaging damaged in transportation not in terms of warranty.
Please register the product within 14 days after the date of purchased.
(The original receipt or e-receipt of the purchase or order number must be attached directly to the company's E-Commerce channel only).